

HI-TECH CLASSROOM REFERENCE MANUAL:

Cable Tuner

**AVT-ITL
486-1774
Fall 2009**

Overview

Some of the classrooms have a Cable TV Tuner which allows HuskyVision programming to be accessed. Please contact AVT-ITL (486-1774) with any inquiries into the Cable TV capabilities of any classroom.

Accessing the Cable Tuner

Push Button Classroom

Select the button labeled “Tuner” from the row of white source buttons. Locate the cable TV tuner within the AV rack. Channel selection can then be controlled via the channel up and channel down buttons on the face of the cable tuner itself; the channel is displayed a window on the unit itself.

Note: If no image appears on the preview monitor, verify that it has been properly set to view this signal type via the signal switch buttons on the preview monitor.

Fixed Touch Screen Classroom

Touch the button labeled “Tuner” from the upper set of source buttons. Controls for the system and channel display will appear when the source is chosen.

Tech-Ready Classroom

This style of classroom does not provide this feature.