


TECH-READY ROOM

System Startup


1. Touch the screen anywhere to begin. This will show the **Welcome Screen**.
2. Press the screen again to display the **Password Page**. (See Department Head for password)
3. Enter the password and touch “Enter” to turn the AV System power on and display the **Main Page** (*see figures below*).



Welcome Page



Password Page



Main Page

4. The External Sources, video and audio, are connected via the **AUXILIARY PLATE** towards the bottom of the unit.
5. Select Source: The Tech-Ready System has 3 sources to select:
 - Computer:** The internal Tower. NOTE: The 2 front USB ports allow connectivity to the tower for Flash Drives, etc.
 - Laptop:** An external Digital source (Laptop or Document Camera)
 - Video:** An external Video source (DVD player, VCR, etc.)
6. After a three minute warm-up, the selected source will be displayed by the projector, adjust volume as necessary via the control panel.

System Shutdown

1. Press the “Press to turn System off” button located in the lower-left portion of the touch screen.
2. If unintentionally powered down, please wait 3 minutes for projector cool-down before re-accessing system.
3. Disconnect any external devices connected via the AUXILIARY PLATE.

PLEASE TURN SYSTEM OFF AT THE END OF YOUR CLASS: THIS PREVENTS SYSTEM FREEZE-UP AND EXTENDS PROJECTOR LAMP LIFE

**FOR ANY QUESTIONS OR PROBLEMS
CALL THE AVT HELPDESK @ 860-486-1774**